



## **OPERATIONS**

1 BACK OF MOULDING TO BE HOLLOW

## **GENERAL NOTES:**

-PL PREMIUM ADHESIVE MUST BE USED ON ALL BEDDING/BUTT JOINTS

## SPECTIS MOULDERS INC.



P.O. BOX 970 100 CEDAR DRIVE NIVERVILLE, MANITOBA CANADA ROA 1E0

PHONE: 204-388-6700 PHONE: 800-685-9981 FAX: 204-388-6710

BOX 479 PEMBINA, NORTH DAKOTA 58271-0479 U.S.A

GENERAL NOTES:

1. ALL PRODUCTS ARE DRAWN FOR PRESENTATION PURPOSSES, ONLY IMAGE MAY VARY SLIGHTLY FROM ACTURAL PART

2. DRAWING INTENT IS TO INDICATE OF THE PROPERTY OF WORK IS PARTLY DIAGRAMATIC.

2. DRAWING INTENT IS TO INDICATE OF THE PROPERTY OF WORK IS PARTLY DIAGRAMATIC.

3. SPECTIS RESERVES THE RIGHT TO CHANGE ANY PRODUCT DESIGN WITHOUT reserved. This document may not be used or duplicate without prior consent.

CUSTOMER NAME:			PART:
STANDARD PRODUCT			MD1154
REFERENCE:			SHEET:
			01 OF 01
DRAWN BY:	DATE:	SCALE:	REV:
JB	06/11/22	1/4 = 1"	