


## 11 Columns to Surround Structural Supports

### DuraLite™ Square Recessed Panel Columns

Measurements in inches unless otherwise noted.

Size	Inside Top Shaft Width P	Largest Round Support	Largest Square Support
<b>Full Length and Knee-Wall Columns</b>			
8"	5 3/4	5 1/4	3 7/8
10"	8	7 1/2	5 5/8



Note: These columns allow for saw kerf as columns are split. Columns that are split are non-load bearing.

### Plan Types for Splitting DuraLite™ Columns



## 10 DuraLite™ Panel Divider Kits

to convert a single panel column into a 2- or 3-panel column

Measurements in inches unless otherwise noted.

Kit Size	Width	Height
8" Panel Divider Kit (4 pieces)	2 1/4	4 7/8
10" Panel Divider Kit (4 pieces)	3 7/8	5 5/16




Note: Each Panel Divider Kit includes four pieces. One Panel Divider Kit is needed to achieve a 2-panel column and two panel divider kits are needed to achieve a 3-panel column. Panel Divider Kits must be purchased separately.