DuraCast™ Fiberglass Columns

Timeless beauty and elegance come standard with all Dixie Pacific® columns. For extreme durability, minimal maintenance, and designs for both interior and exterior applications, DuraCast™ Fiberglass Columns are exactly what you've been looking for.

Choosing the Right DuraCast™ Column

- 1. Choose the column style: round, square, tapered or non-tapered; plain or fluted.
- 2. Choose the appropriate column size.
- 3. Select the appropriate cap and base.

DuraCastTM Columns are designed for all types of decorative and load-bearing installations. They are manufactured from highly advanced fiberglass reinforced polymers (FRP), which makes them very durable. All components are insect, weather, and decay resistant and carry a limited lifetime warranty. With architecturally correct proportions and projections, DuraCastTM Columns are available in a range of styles to fit any project. Each must pass quality control inspections before it is shipped, making sure that each represents the unmistakable Dixie craftsmanship.



- Round or Square
- Architecturally Correct Proportions
- Plain or Fluted Shaft
- Durable
- Low Maintenance

- Decay Resistant
- Load Bearing
- Decorative Capitals Available
- Limited Lifetime Warranty





Panel

(Plain or

(Plain or

Caps & Base/Plinths for DuraCast™ Columns

See Page 7 for details

TUSCAN CAP & BASE

Roman Doric CAP & BASE

COLONY CAP & BASE Аттіс









Decorative Capitals for DuraCast™ Columns

Angular Greek Ionic

Angular Greek Ionic

DECORATIVE ROMAN Doric







Empire

EMPIRE W/ NECKING

GREEK ERECTHEUM







GREEK ERECTHEUM W/

NECKING






Modern

COMPOSITE







Fiberglass Column Installation Kit



Use during installation to secure column shaft in place.

Each Kit Includes:

(4) Brackets (2 top; 2 bottom) (10) 2" Stainless Screws (10) Tapcon Screws

Split Column Assembly Kit

Dixie Pacific® offers a split column assembly kit that utilizes a mechanical fastening system for easy and secure assembly. This kit can be purchased separately when ordering a factory split column or they can be ordered pre-installed on factory split columns. This kit is available on select sizes.

Plan Types for Split DuraCast™ Columns















DuraCast™ Round Tapered Columns



Size	Bottom Dia	Neck Dia	Base Plinth Width	Base Plinth	Base Moulding	Capital Square Width	Capital Square	Capital Round	Bead	Bottom Flute	Top Flute	Flute Width	Above Bead	Number of Flutes	Lengths Available
	A	В	С	D	Е	F	G	Н	- 1	J	K	L	М	-	
6"	5-5/8"	5-1/2"	8-1/4"	1-1/2"	1-3/4"	7-1/8"	1-1/8"	5/8"	1″	10-3/4"	1″	5/16"	3-1/4"	16	5′, 6′, <mark>8′)</mark> 9′, 10′
8"	7-5/8"	6 1/2"	10-1/4"	1-7/8"	2-3/8"	9-9/16"	1-3/8"	1″	1″	10-3/4"	1″	11/16"	4-1/4"	24	5'-6", 6', 8', 9', 10'
10"	9-5/8"	8-1/2"	12-7/8"	2-3/8"	2-7/8"	11-7/8"	1-3/4"	1-1/4"	1″	10-3/4"	1″	7/8"	5-1/8"	24	6', 8', 9', 10', 12'
12"	11-5/8"	10"	15-1/4"	2-3/4"	3-1/4"	14-1/2"	2"	1-3/8"	1″	10-3/4"	1″	1″	5-7/8"	24	6', 8', 9', 10', 12', 14', 16'
14"	13-5/8"	12"	18-3/4"	3-3/8"	4"	17-1/4"	2-3/8"	1-5/8"	1-1/8"	10-3/4"	1″	1″	6-7/8"	24	8', 9', 10', 12', 14', 16'
16"	15-5/8"	13-1/2"	21-1/4"	3-7/8"	4-1/2"	19-1/4"	2-3/4"	1-7/8"	1-1/4"	10-3/4"	1″	1-1/4"	7-1/2"	24	8', 9', 10', 12', 14', 16', 18', 20'
18"	17-1/2"	15-3/8"	24-5/8"	4"	5-5/8"	22-3/8"	3-1/8"	2-3/4"	1-1/8"	10-3/4"	1-1/2"	1-3/8"	8-7/8"	24	10, 12, 14, 16, 18, 20, 22, 24, 26
20"	19-1/2"	17-3/16"	27"	4-3/4"	6-1/2"	24-15/16"	3-3/8"	2-7/8"	1-7/16"	10-3/4"	1-1/2"	1-3/8"	9″	24	10, 12, 14, 16, 18, 20, 22, 24
22"	21-5/8"	19-1/4"	30-1/4"	5-3/8"	6-7/8"	27-1/2"	3-3/4"	3"	1-7/8"	10-3/4"	1-1/2"	1-11/16"	10-1/4"	24	16, 18, 20, 22, 24, 26
24"	23-5/8"	21-1/4"	33-1/2"	5-7/8"	7-7/16"	30-1/2"	4-1/16"	3-1/2"	2-3/16"	10-3/4"	1-1/2"	1-11/16"	11-5/16"	24	12, 14, 16, 18, 20, 22, 24, 26, 28, 30
28"	28"	24-1/8"	38"	6-3/4"	8-3/4"	33-3/8"	4-3/4"	3-1/4"	2-1/8"	10-3/4"	1-1/2"	2"	11-3/4"	24	20, 22, 24, 26, 28
30"	29-5/8"	26-1/2"	41-1/8"	6-1/2"	8-3/8"	38-1/4"	4-5/8"	4"	3-1/16"	10-3/4"	1-1/2"	2"	14-7/8"	24	20, 22, 24, 26, 28, 30




NOTE: • Custom Fluted Columns are available.


- Custom sizes are available. Contact Dixie Pacific® for more information.
- Standard Fluted Column (Fluted in mold)


Columns to Surround Structural Supports

for DuraCast[™] Round Tapered Columns

Size	Max Round Support	Max Square Support
6"	3"	2 1/2"
8"	5 1/4"	3 11/16"
10"	6 7/8"	4 13/16"
12"	8 7/16"	5 7/8"
14"	10 1/16"	7 1/8"
16"	12 7/8"	9 1/8"
18"	14 3/8"	10 3/16"
20"	16 5/8"	11 3/4"
22"	18 1/4"	12 7/8"
24"	20 1/4"	14 1/4"
28"	22"	15 1/2"
30"	25 1/4"	17 3/4"







- Columns that are split are non-load-bearing. Splitting a column will decrease inside dimension ¹/₈".
- Specify shape and size of structural support






Measurements in inches unless otherwise noted. There may be a variance of up to $^{1/4}$ " in all dimensions. NOTF:

- Tuscan Cap and Base are standard components for DuraCastTM Columns.
- All Caps and Base are non-vented.
- All Caps and Base are sold separately from the column.






Column	Plinth		Base	Cap (S	quare)	Сар
Size	Width	Height	Mould	Width	Height	(Round)
	С	D	E	F	G	Н
6″**	8-1/4"	1-1/2"	1-3/4"	7-1/8"	1-1/8"	5/8"
8"**	10-1/4"	1-7/8"	2-3/8"	9-9/16"	1-3/8"	1″
10"**	12-7/8"	2-3/8"	2-7/8"	11-7/8"	1-3/4"	1-1/4"
12″**	15-1/4"	2-3/4"	3-1/4"	14-1/2"	2"	1-3/8"
14"*	18-3/4"	3-3/8"	4"	17-1/4"	2-3/8"	1-5/8"
16″*	21-1/4"	3-7/8"	4-1/2"	19-1/4"	2-3/4"	1-7/8"
18″*	24-5/8"	4"	5-5/8"	22-3/8"	3-1/8"	2-3/4"
20"*	27"	4-3/4"	6-1/2"	24-15/16"	3-3/8"	2-7/8"
22"*	30-1/4"	5-3/8"	6-7/8"	27-1/2"	3-3/4"	3"
24"*	33-1/2"	5-7/8"	7-7/16"	30-1/2"	4-1/16"	3-1/2"
28"*	38"	6-3/4"	8-3/4"	33-3/8"	4-3/4"	3-1/4"
30"*	41-1/8"	6-1/2"	8-3/8"	38-1/4"	4-5/8"	4"

NOTE:

- Available in Polyurethane and Injection Molded (SIM/ER) for 6"-12".
- It is not recommended to split Injection Molded (SIMVER) Cap and Base sets for reassembly.
- Tuscan (SIM/ER) Cap and Base components can only be purchased as a set.
- Tuscan cast fiberglass Caps and Bases are available for 6"-16".

Colony Cap & Base




Column	Pli	nth	Base	Cap (S	quare)	Сар
Size	Width	Height	Mould	Width	Height	(Round)
	С	D	E	F	G	Н
6″*	7-7/8"	1-1/4"	1-1/2"	7"	1	5/8"
8"**	9-7/8"	1-1/4"	1-1/2"	9-3/8"	1″	1″
10"**	11-7/8"	1-1/4"	1-1/2"	11-3/8"	1-1/4"	1″
12″*	13-3/4"	1-1/4"	1-1/2"	12-7/8"	1-3/8"	1″

NOTE:

- Available in Polyurethane and Injection Molded (SIM/ER) for 8"-10".
- It is not recommended to split Synthetic Injection Molded (SIM/ER) Cap and Base sets for reassembly.
- Colony (SIM/ER) Cap and Base components can only be purchased as a set.

Roman Doric Cap & Base



Column	Pli	nth	Base	Cap (S	Cap	
Size	Width	Height	Mould	Width	Height	(Round)
	С	D	E	F	G	Н
6" *	81/2	11/2	13/4	71/8	11/8	5/8
8" *	103/8	17/8	27/16	93/4	1 ⁷ / ₁₆	11/16
10" *	1215/16	$2^{3/_{8}}$	31/8	121/2	13/4	1%16
12" *	15 ¹ / ₄	$2^{3/_{4}}$	31/2	$14^{3/_{4}}$	$2^{3/_{16}}$	11/2
14" *	185/8	33/8	4 ¹ / ₁₆	171/2	25/16	21/16
16" *	211/2	37/8	4 ⁷ / ₈	19 ⁷ / ₈	25/8	21/16
18" *	231/4	4	6	231/8	3	13/4

NOTE

• Roman Doric cast fiberglass Caps and Bases are available for 6"-16".

Attic Base



Column	Plir	Base		
Size	Width	Height	Mould	
	C	D	E	
6" *	81/2	11/2	27/16	
8" *	101/4	17/8	31/4	
10" *	13	23/8	37/8	
12" *	151/4	23/4	41/2	
14" *	18 ⁵ / ₈	33/8	53/8	
16" *	211/2	37/8	61/4	
18" *	25	43/8	71/4	
20" *	2711/16	4 ⁷ / ₈	81/4	
22" *	301/4	5 ³ / ₈	$9^{1/_{4}}$	
24" *	331/2	6	101/4	
28" ***	38	63/4	113/8	
30" *	411/4	61/2	1111/4	

NOTE:

• Attic cast fiberglass bases are available.

^{*} Manufactured from polyurethane.

^{**} Manufactured from polyurethane or Synthetic Injection Molded (SIM/ER).

^{***} Manufactured from fiberglass.

DECORATIVE CAPITALS FOR DURACASTTM ROUND TAPERED COLUMNS



on't settle for anything less than the top of the line for the top of your column. Reminiscent of time-honored architectural styles, Dixie Pacific's® wide range of Decorative Capitals allows you to make a modern-day statement for any fiberglass or paint-grade wood column for both interior and exterior applications.


Decorative Capital Features:

- 12 Styles and Numerous Sizes Available
- Decay Resistant
- Hand Crafted with Precise Detail
- · Manufactured from Lightweight Polyurethane
 - 6"-12" are Load-Bearing
 - 14"-30" Requires Load-Bearing Plug
- Limited Lifetime Warranty

Cutting Columns at Bead/Astragal

A. All DuraCast™ Round Tapered Fiberglass Columns and Paint-Grade (6" x 8'- 12" x 12') Round Tapered

Wood Columns used with Decorative Capitals should be cut flush above the bead.



B. The Decorative Capital should rest on top of the bead to allow for a proper fit on the column.

The "cut at bead" loss and the Decorative Capital height must be taken into consideration when ordering columns. A column used with a short Decorative Capital may require a longer shaft.




Plan Types for Split Decorative Capitals




"Cut At Bead" Loss for DuraCast™ Round Tapered Fiberglass Columns Measurement in inches unless otherwise noted.

Column Size	"Cut at Bead" Loss
6"	3-1/4"
8"	4-1/4"
10"	5-1/8"
12"	5-7/8"
14"	6-7/8"
16"	7-1/2"
18 ^{II}	8-7/8"
20 ¹¹	9"
22"	10-1/4"
24"	11-5/16"
28 ^{II}	11-3/4"
30 ¹¹	14-7/8"







- 8" 12" Decorative Capitals are load bearing (unless split) and manufactured from lightweight polyurethane.
- 14" 30" Decorative Capitals are non-load bearing (requires plug) and manufactured from lightweight polyurethane.
- Specify shape and size of structural support if Decorative Capitals are split for reassembly. The inside diameter of the Decorative Capital is significantly smaller than the inside top diameter of the column shaft.
- Fiberglass Decorative Capitals are available.
- **Necking detail may vary.



Greek Erectheum with Necking**



Greek Ionic



Greek Erectheum



Angular Greek Ionic



Angular Greek Ionic with Necking**



Scamozzi



Roman Ionic



Empire



Empire with Necking**



Decorative Roman Doric



Roman Corinthian

[8]



Measurements in inches unless otherwise noted. There may be a variance of up to $\frac{1}{4}$ " in all dimensions.


DuraCast™ Round Non-Tapered Columns

Custom flutes available

Column Size	Bottom Shaft Diameter	Neck Shaft Diameter	Bead (Applied)	Length (in feet)
	Α	В	K	
6"	5 ⁵ / ₈	5 ³ / ₈	3/4	8, 9
8"	7 ⁵ / ₈	7 ⁵ / ₈	3/4	6, 8, 9, 10
10"	95/8	95/8	3/4	6, 8, 9, 10, 12
12"	11 ⁵ / ₈	115/8	¹³ / ₁₆	6, 8, 9, 10, 12
14"	135/8	135/8	⁷ / ₈	6, 8, 9, 10, 12, 14
16"	$15^{3}/_{4}$	153/4	1	6, 8, 9, 10, 12, 14, 16, 18, 20
18"	171/2	17 ¹ / ₂	11/8	6, 8, 9, 10, 12, 14, 16, 18, 20
24"	24	24	2³/ ₁₆	8, 10, 12, 14, 16, 18, 24

NOTE: • All DuraCast™ fluted columns have adjustable flutes which can be altered.


- Beads are sold separately.
- Custom sizes are available. Contact Dixie Pacific® for more information.




Columns to Surround Structural Supports

for DuraCast™ Round Non-Tapered Columns

Column Size	Inside Top Shaft Diameter	Top View
	P	
8"	$6^{7/8}$	Inside
10"	87/8	Diameter
12"	107/8	Diameter
14"	12 ⁷ / ₈	
16"	15	
18"	163/8	
24"	21	



• Specify shape and size of structural support.




Tuscan Cap & Base

for DuraCastTM Round Non-Tapered Columns



Column	Plii	nth	Base	Cap (S	Cap	
Size	Width	Height	Mould	Width	Height	(Round)
	С	D	E	F	G	Н
6"	81/4	11/2	13/4	81/4	11/8	5/8
8"	$10^{1/_{2}}$	1 ⁷ / ₈	21/2	10 ⁵ / ₈	11/2	11/4
10"	13 ¹ / ₈	$2^{3}/_{8}$	27/8	$12^{13}/_{16}$	$1^{3}/_{4}$	11/4
12"	161/2	27/8	31/4	15 ⁷ / ₈	2	13/4
14"	$19^{1/_{2}}$	33/8	$4^{1}/_{4}$	19 ¹ / ₈	3	21/4
16"	221/8	4	45/8	22	23/4	21/4
18"	245/8	4	5 ⁵ / ₈	245/8	31/8	$2^{3}/_{4}$
24"	331/2	$5^{3/_{4}}$	7 ⁷ / ₁₆	333/8	41/8	31/2










DuraCast™ Craftsman Column Dimensions

	A	В	C	D	E	F	G	J	K	L	R	LENGTH
10" x 5 ¹ / ₂ "	10"	51/2"	13"	21/2"	23/8"	11/16"	1"	1³/s"	1 ³ / ₈ "	95/8"	5 ⁷ /8"	66"
10 ¹ / ₄ " x 7 ¹ / ₂	101/4"	71/2"	131/2"	23/8"	21/4"	3/4"	1"	1"	1"	101/4"	53/8"	7'
10" x 8"	91/2"	71/2"	123/4"	23/8"	21/8"	3/4"	1"	1"	1 ³ / ₈ "	101/4"	51/4"	66"
12" x 10"	12"	10"	16 ⁹ /16"	21/2"	21/2"	11/16"	1"	1³/s"	13/8"	123/4"	61/16"	6', 10'
14" x 12"	14"	12"	18 ³ / ₄ "	33/8"	3"	1"	1"	1 ⁵ /8"	2"	17 ¹ /8"	7 ³ /8"	91
16" x 9"	16"	9"	18³/4"	21/2"	21/2"	11/16"	1"	1³/s"	1 ³ /8"	13 ¹ / ₄ "	61/16"	58"
16" x 9"	16"	9"	191/16"	21/2"	21/2"	11/16"	1"	1³/s"	13/8"	13 ¹ /4"	61/16"	6', 8'
16" x 12"	15 ¹ / ₄ "	11 ¹ / ₂ "	211/2"	3 ⁷ /8"	35/16"	1 ³ / ₁₆ "	1"	1 ³ /8"	2"	15¹/₄"	8 ⁷ /16"	58", 6', 8'

NOTE: Neck mould is not applied. Flashing and Installation Kit is not available for Craftsman Columns with Poly Tuscan cap and base sets.

DuraCast™ Craftsman Tapered Columns

Column Size	Тор	Bottom	
10" x 5 ¹ / ₂ "	4 ¹ /2"	9"	
10 ¹ /4" x 7 ¹ /2"	61/2"	91/4"	l
10" x 8"	61/2"	81/2"	
12" x 10"	9"	11"	▎┗
14" x 12"	11"	13"	
16" x 9"	8"	15"	
16" x 12"	101/2"	14 ¹ /2"	




NOTE: • Inside width may vary up to 1/4".

- These columns allow for saw kerf as columns are split. Columns that are split are non-load-bearing. Splitting a column will decrease inside dimension 1/8".
- Specify shape and size of structural support.

Tuscan Cap & Base








www.dixiepacific.com



Measurements in inches unless otherwise noted. There may be a variance of up to 1/4" in all dimensions.



Versatility of Square Columns

The design and versatility of a Dixie Pacific® square column has enhanced its popularity with today's architects. The Dixie Square DuraCast™ column line up includes plain, recessed panel, and fluted. An unlimited combination of styles can be achieved by various uses of the panel moulding, neck moulding, and caps and bases. Additionally, the square column is not tapered and can be cut to any height without affecting the fit of the caps and bases.

RECESSED PANEL INSIDE DIMENSION

Inside dimension may vary up to 1/8".

Splitting a column will decrease inside dimension 1/8".

Col. Size	Inside	
8"	55/8"	1
10"	71/2"	Inside Dimension
12"	91/211	
14"	11"	

COLONY SQUARE CAP AND BASE											
Col. Size	С	D E F J K				L	R				
6"	81/8"	11/4"	1 1/16"	7/ ₁₆ "	5/8"	1"	77/16"	23/4"			
8"	101/8"	11/4"	1 1/16"	⁷ / ₁₆ "	¹⁵ / ₁₆ "	1"	97/16"	23/4"			
10"	121/8"	11/4"	1 1/16"	⁷ / ₁₆ "	¹⁵ / ₁₆ "	11/4"	121/8"	23/4"			
12"	141/8"	11/4"	1 1/16"	⁷ / ₁₆ "	1"	13/8"	141/4"	23/4"			

- Neck moulding is 4 pieces included with the cap and base.
- Low profile cap and base designed for railing applications.


SQUARE DURACAST™ RECESSED PANEL COLUMN DIMENSIONS*

Column Size	A	С	D	E	F	G	J	K	L	N	0	R	S	Recess Depth	Lengths Available (ft.)
8"	8"	111%"	1%"	1¾"	5/8"	1"	13/8"	1¾"	1015/16"	12"	7"	41/4"	1½"	1/2"	8,9,10
10"	10"	131/16"	2¼"	23/16"	3/4"	1¼"	1¼"	1 13/16"	12¾"	14½"	8½"	53/16"	1½"	1/2"	8,9,10
12"	12"	16%6"	213/16"	23/8"	⁷ /8"	1¼"	1¾"	21/16"	1611/16"	18"	10½"	61/16"	21/4"	%6 "	8,9,10,12,14
14"	14"	19¾"	35/8"	2½"	11/16"	11/8"	21/16"	2½"	191/16"	21"	121/4"	7%6"	25/8"	3/4"	8,10,14

* With Tuscan Cap and Base

Square Column with Tuscan Cap and Base

DuraCast™ Square Columns




Square DuraCast[™] Inside Dimensions

Inside dimensions may vary up to $^{1}/_{8}$ ". Splitting a column will decrease inside dimension $^{1}/_{8}$ ".

	INSIDE	COL. SIZE
A	51/4"*	6"
Inside	67/8"	8"
Dimension	9"	10"
	11"	12"
· ·	143/4"	16"

*Inside is Round



SOUARE	DuraCast™	COLUMN	DIMENSIONS*
JQUAKL	DUKACASI	COLUMIN	DIMENSIONS

			•										
Column Size	A	С	D	E	F	G	J	K	L	N	О	R	Lengths Available (ft.)
6"	6"	9½"	1%"	1%"	%6"	1"	1¼"	1%"	9½"	N/A	N/A	3%"	6,8,9,10
8"	8"	111%"	1%"	1¾"	5/8"	1"	1¾"	1%"	1015/6"	4"	31/811	4¼"	6891012
10"	10"	131/46"	2¼"	23/16"	3/4"	1"	1¼"	113/6"	12¾"	4"	4¹/8"	5%"	51",6,8,9, <mark>10</mark> 12 14,16
12"	12"	16%6"	213/16"	2¾"	⅓"	1"	1¾"	21/16"	1611/16"	N/A	N/A	61/16"	8,9,10,12,14,16,18
14"	14"	191/8"	31/8"	27/8"	11/16"	1"	21/16"	21/2"	191/16"	N/A	N/A	79/16"	8,10,12,14 16,18,20
16"	16"	221/8"	37/8"	33/8"	11/8"	1"	23/8"	23/4"	211/2"	N/A	N/A	83/8"	8,10,12,14, 16,18,20

☐ Fluted Square.

*With Tuscan Cap and Base.