Measurements in inches unless otherwise noted. Bottom Load-Bearing Neck Shaft Width Shaft Width Min. Wall Panel Width **Bottom** Capacity* Тор Length Size Bead Insert Thickness Insert (in Ibs.) (in feet) 8" 7 1/2 7 1/2 4 7/8 8 1/8 6,500 6, 8, 9, 10, 12 9 1/2 10" 9 1/2 5 5/16 7,000 6, 8, 9, 10, 12

*Load-bearing capacity is dependent on the concentric loading of the column. Eccentric (non-centered) load-bearing capacity available upon request.

Note: 2nd story balconies should not be attached directly to the side of any column, contact Dixie-Pacific* for recommendations.

9 DuraLite™ Square Non-Tapered Recessed Panel Knee-Wall Columns Measurements in inches unless otherwise noted.

Size	Bottom Shaft Width A	Neck Shaft Width B	Bead K	Panel Width	Top Insert M	Bottom Insert	Min. Wall Thickness	Load-Bearing Capacity* (in lbs.)	Length (in feet)
8″	7 1/2	7 1/2	1	4 7/8	8	8	1/8	6,500	Up to 6
10"	9 1/2	9 1/2	1	5 5/16	9	9	1/8	7,000	Up to 6
1		1							



*Load-bearing capacity is dependent on the concentric loading of the column. Eccentric (non-centered) load-bearing capacity available upon request.

Note: 2nd story balconies should not be attached directly to the side of any column, contact Dixie-Pacific* for recommendations.

Note: Each Panel Divider Kit includes four pieces. One Panel Divider Kit is needed to achieve a 2-panel column and two panel divider kits are needed to achieve a 3-panel column. Panel Divider Kits must be purchased separately.

